



Quick Connector Installation Guide

To install our LED Light pods using our Quick Connector terminals, please follow these instructions.

After connecting the power wire to the battery, fuse holder and switch and/ or optional remote, lift all the orange securing levers on Quick Connect terminals. When the securing lever is in the up position, it allows you to insert the wire into the terminal. When the securing lever is in the down position, it locks the wiring into the terminal.

Strip each wire that will be connected to the terminal back 10mm. Run the negative power wire into one terminal, and run the positive wire into the another terminal. Use two separate Quick Connect terminals for installation, one for all the negative (-) wires, and a separate one for all the positive (+) wires (Never combine both negative and positive wires in the same Quick Connect terminal, this will result in damage to your LED Lighting Kit and/ or vehicle).

Continue filling each terminal with the appropriate wires until all lights are connected. Secure the Quick Connect terminals to the vehicle using double sided tape or zip ties, making sure to mount them away from any high temperature objects like an exhaust.

Remember, it is ok to have multiple wires connected and secured by one lever, but try to spread out the wiring evenly through the securing levers of the Quick Connect terminal.

Note: For those individuals that are not technically inclined, we would strongly recommend that you bring your vehicle to your local mechanic or installer and have them install the part or parts for you. Pivotal Powersports Corp. is not responsible for the installation of any of our products.

If you have any additional questions, please contact us at Sales@PivotalPowersports.com Thanks!

