




## Remote Control Installation Instructions



Find a clean and dry location to mount the control unit. This remote control system is not waterproof, so assure that the control unit and the remote handset transmitter does not get wet. Attach the unit to the surface using double sided tape or plastic zip ties.

The blue color wire is the ANTENNA wire; it should not be connected to any other wire and also be positioned as high as possible to increase the remote control range.

The black color wires are the GROUND wires; they should be connected to the power source ground and the device's ground that is being controlled.

The red wire is the POWER IN; it should be connected to the 12 volt power source.

The white wire is the POWER OUT; it should be connected to the 12 volt product that is being controlled.

Press the ON or OFF buttons on the handset transmitted to activate or deactivate the product you are controlling.

When the battery on the handset transmitter gets low, the operating range will decrease as well. Replace the battery to remedy.